





INSTRUCTIUNI DE MONTAJ




USI DE DUS
RAPID FOLD





















NECESARE INSTRUMENTE



PĂRȚI



1



L
685-715
785-815
885-915
985-1015

